

**SOS Quick Reference Guide
Hypocardioid Microphones
(10dB back attenuation)
Plan No 213**

**Front Triplet Coverage = 100° + 100°
Lateral Segment Coverage = 50°
Back Pair Coverage = 60°**

