

**SOS Quick Reference Guide**  
**Hypocardioid Microphones**  
**(10dB back attenuation)**  
**Plan No 2301**

**Front Triplet Coverage = 70° + 70°**  
**Lateral Segment Coverage = 85°**  
**Back Pair Coverage = 50°**

