

**SOS Quick Reference Guide**  
**Hypocardioid Microphones**  
**(10dB back attenuation)**  
**Plan No 1388**

**Front Triplet Coverage = 80° + 80°**  
**Lateral Segment Coverage = 60°**  
**Back Pair Coverage = 80°**

