

**SOS Quick Reference Guide**  
**Hypocardioid Microphones**  
**(10dB back attenuation)**  
**Plan No 721**

**Front Triplet Coverage = 90° + 90°**  
**Lateral Segment Coverage = 55°**  
**Back Pair Coverage = 70°**

