

**SOS Quick Reference Guide  
Supercardioid Microphones  
(11.5dB back attenuation)  
Plan No 126**

**Front Triplet Coverage = 100° + 100°  
Lateral Segment Coverage = 55°  
Back Pair Coverage = 50°**

