

**SOS Quick Reference Guide  
Supercardioid Microphones  
(11.5dB back attenuation)  
Plan No 111**

**Front Triplet Coverage =  $100^\circ + 100^\circ$   
Lateral Segment Coverage =  $45^\circ$   
Back Pair Coverage =  $70^\circ$**

