

**SOS Quick Reference Guide
Supercardioid Microphones
(11.5dB back attenuation)
Plan No 102**

**Front Triplet Coverage = 100° + 100°
Lateral Segment Coverage = 35°
Back Pair Coverage = 90°**

