

**SOS Quick Reference Guide
Supercardioid Microphones
(11.5dB back attenuation)
Plan No 56**

**Front Triplet Coverage = 100° + 100°
Lateral Segment Coverage = 55°
Back Pair Coverage = 50°**

