

**SOS Quick Reference Guide
Supercardioid Microphones
(11.5dB back attenuation)
Plan No 58**

**Front Triplet Coverage = $100^\circ + 100^\circ$
Lateral Segment Coverage = 55°
Back Pair Coverage = 50°**

