

**SOS Quick Reference Guide  
Supercardioid Microphones  
(11.5dB back attenuation)  
Plan No 46**

**Front Triplet Coverage = 100° + 100°  
Lateral Segment Coverage = 50°  
Back Pair Coverage = 60°**

