

**SOS Quick Reference Guide  
Supercardioid Microphones  
(11.5dB back attenuation)  
Plan No 1941**

**Front Triplet Coverage = 70° + 70°  
Lateral Segment Coverage = 90°  
Back Pair Coverage = 40°**

