

**SOS Quick Reference Guide
Supercardioid Microphones
(11.5dB back attenuation)
Plan No 1902**

**Front Triplet Coverage = 70° + 70°
Lateral Segment Coverage = 90°
Back Pair Coverage = 40°**

