

**SOS Quick Reference Guide
Supercardioid Microphones
(11.5dB back attenuation)
Plan No 1308**

**Front Triplet Coverage = 80° + 80°
Lateral Segment Coverage = 60°
Back Pair Coverage = 80°**

