

**SOS Quick Reference Guide**  
**Supercardioid Microphones**  
**(11.5dB back attenuation)**  
**Plan No 1310**

**Front Triplet Coverage = 80° + 80°**  
**Lateral Segment Coverage = 60°**  
**Back Pair Coverage = 80°**

