

**SOS Quick Reference Guide**  
**Supercardioid Microphones**  
**(11.5dB back attenuation)**  
**Plan No 732**

**Front Triplet Coverage = 90° + 90°**  
**Lateral Segment Coverage = 50°**  
**Back Pair Coverage = 80°**

