

**SOS Quick Reference Guide  
Supercardioid Microphones  
(11.5dB back attenuation)  
Plan No 714**

**Front Triplet Coverage = 90° + 90°  
Lateral Segment Coverage = 65°  
Back Pair Coverage = 50°**

