

**SOS Quick Reference Guide
Supercardioid Microphones
(11.5dB back attenuation)
Plan No 705**

**Front Triplet Coverage = 90° + 90°
Lateral Segment Coverage = 55°
Back Pair Coverage = 70°**

