

**SOS Quick Reference Guide**  
**Supercardioid Microphones**  
**(11.5dB back attenuation)**  
**Plan No 660**

**Front Triplet Coverage = 90° + 90°**  
**Lateral Segment Coverage = 65°**  
**Back Pair Coverage = 50°**

