

**SOS Quick Reference Guide
Supercardioid Microphones
(11.5dB back attenuation)
Plan No 600**

**Front Triplet Coverage = 90° + 90°
Lateral Segment Coverage = 60°
Back Pair Coverage = 60°**

