

**SOS Quick Reference Guide
Supercardioid Microphones
(11.5dB back attenuation)
Plan No 591**

**Front Triplet Coverage = $90^\circ + 90^\circ$
Lateral Segment Coverage = 50°
Back Pair Coverage = 80°**

