

SOS Quick Reference Guide
Supercardioid Microphones
(11.5dB back attenuation)
Plan No 592

Front Triplet Coverage = $90^{\circ} + 90^{\circ}$
Lateral Segment Coverage = 50°
Back Pair Coverage = 80°

